




N	Code	Description	Initial serial number
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16	1.046726	Safety valve	
17			
18			
19			
20			
21	1.046432	"Y" filter	
22	1.046420	Wired controller	
23			
24			
25			
26			
27			
28	1.046728	Principal PCB	
29	1.046727	Expansion vessel (8 litres)	
30			
31			
32			
33			
34	1.046720	Return temperature pipe	
35	1.046721	Return temperature water	
36			
37	1.047364	Room temperature sensor	
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			

N	Code	Description	Initial serial number
49			
50			
51	1.046729	Pressure switch	
52	1.047383	Low voltage wire	
53			
54			
55			
56	1.046735	Exchanger electrical heater	
57	1.046724	Heat exchanger gasket	
58	1.046725	Temperature sensing assembled pipe	
59			
60			
61			
62			
63	1.046722	Pressure sensor	
64			
65	1.046734	Electrical heater	
66	1.046901	Drain valve	